

Disclaimer

Legal disclaimer

This guide and its contents (the "Guide") are provided by NXGEN. All rights to the Guide and to the intellectual property embodied in it — including, without limitation, trademarks, trade names, logos and similar marks appearing in or on it — are protected by law. All right, title and interest in the Guide and in any related intellectual property rights belong to and remain with NXGEN and its licensors.

The Guide is provided free of charge, "as is" and for informational purposes only, without warranty of any kind. It is neither intended nor suitable to establish any legal relationship between the reader and NXGEN or its affiliates, including, without limitation, any obligation of NXGEN or its affiliates toward the reader.

The obligations of NXGEN and its affiliates in respect of NXGEN products or services purchased by a customer are governed exclusively by the terms of the agreement under which those products or services were purchased.

For clarification

The reader bears the entire risk as to the use, results and performance of the Guide. To the fullest extent permitted by applicable law, NXGEN disclaims and excludes all warranties, whether statutory, express or implied — including, without limitation, implied warranties of merchantability, fitness for a particular purpose, title and non-infringement of third-party rights — as well as any liability or warranty arising from suggestions, specifications or samples related to the Guide.

Troubleshooting Alarms

Updated 23 September 2026

This guide provides troubleshooting steps to resolve issues when no alarms are received from a device integrated with GC Surge. For platform, activation and SMTP issues beyond the device itself, see

[Troubleshooting Guide](#). Covers: Symptom: No Alarms Received from Camera.

Symptom: No Alarms Received from Camera

If GC Surge is not receiving alarm events or video clips from a configured camera, perform the following troubleshooting checks in order:

1. Check if motion events are enabled Verify that motion detection is active on your camera's administrative interface. Make sure the motion detection zones are correctly configured and that sensitivity thresholds are high enough to trigger events.
2. Check if SMTP credentials are added and valid GC Surge often relies on SMTP/email alerts sent by the camera to ingest alarm events. Check the camera's SMTP settings. Verify that the server address, port, email address, username, and password are correct. Run a test email from the camera interface to confirm.
3. Verify camera network connectivity Ensure that the camera has internet access and can reach the external SMTP/API server. Check DNS configurations on the camera so it can resolve external domains.
4. Verify alarm schedules Check the schedule settings in the camera's configuration. Ensure that motion events and alarm transmissions are scheduled to run 24/7 or during your desired active shifts.
5. Inspect camera system logs Access the camera's log section and look for any SMTP connection errors, authentication failures, or event trigger failures. This can provide specific error codes for further troubleshooting.